


Layout diagram leXsolar-EMobility Large

Item-No.1802

Bestückungsplan leXsolar-EMobility Large

Art.-Nr.1802



- | | | |
|--|---|---|
| <p>1 L2-06-067 Reversible Fuel cell Pro
L2-06-067 Reversible Brennstoffzelle Pro</p> <p>2 1800-15 Distilled water (100 ml)
1800-15 Destilliertes Wasser (100 ml)</p> <p>3 1118-11 Capacitor module Pro
1118-11 Kondensatormodul Pro</p> <p>4 1118-09 Battery module NiMH 3xAAA Pro
1118-09 Akkumodul NiMH 3xAAA Pro</p> <p>5 1800-01 Resistor module (triple) Pro
1800-01 Widerstandsmodul 3-fach Pro</p> | <p>6 1100-62 Potentiometer module 110 Ohm Pro
1100-62 Potentiometermodul 110 Ohm Pro</p> <p>7 1801-07 leXsolar-Base unit EMobility
1801-07 leXsolar Grundeinheit EMobility</p> <p>8 1800-08 Battery module holder 1xAAA Pro
with L2-04-021 NiMH battery AAA
1800-08 Akkuhalterungsmodul 1xAAA Pro
mit L2-04-021 NiMH-Akku AAA</p> <p>9 Battery adapter for 13
Akku-Adapter für 13</p> | <p>10 1801-06 LiFePo-battery AAA
1801-06 LiFePo-Akku AAA</p> <p>11 L2-04-102 NiZn-battery AAA
L2-04-102 NiZn-Akku AAA</p> <p>12 1800-04 Resistor plug element 100 Ohm
1800-04 Widerstands-Steckelement 100 Ohm</p> <p>13 1801-02 Electric model car with 9
1801-02 Elektro-Modellfahrzeug mit 9</p> <p>14 2x1800-05 Resistor plug element 10 Ohm
2x1800-05 Widerstands-Steckelement 10 Ohm</p> <p>15 1800-03 Resistor plug element 1 Ohm
1800-03 Widerstands-Steckelement 1 Ohm</p> |
|--|---|---|

Version number
Versionsnummer

L3-03-166_16.03.2016